

It's broken – now what?

Does not go off – NO light!

POSSIBILITIES

Broken wire in epee, body cord or reel
Blade wire broken at guard socket
Contact spring too short
Contact spring bent
Internal short in epee
Body cord wired incorrectly

Will not pass the weight test!

POSSIBILITIES

Weak pressure spring
Barrel dented or out of round

Will not pass the shim test!

POSSIBILITIES

Contact Spring is too long

Phantom touches

POSSIBILITIES

Intermittent internal short of the wires due to a loose barrel
Metallic flake inside the point
Loose wires in the guard socket